

# Chapter 1. Disassembly & Assembly Guide

---


## 1-3. Disassembly & Assembly

### - LCD Block -

#### L-1 LCD Block Disassembly

## Cap (Hinge)


1)



Peel off the Cap (Hinge) (two places).


# Cover (Hinge)

1)



Put aside the Harness toward the right, and remove the Cover (Hinge-R) while disengaging the detent (three places).


2)



Put aside the Harness and the coaxial cable in the direction of the arrow.

3)


**Camera Model**



Disengage the detent (three places), and remove the Cover (Hinge-L) while taking out the Camera Harness from the hole.

4)


**No-Camera Model**



While disengaging the detent (three places), remove the Cover (Hinge-L).

## Bezel -1


1)



Remove the two screws.

## Bezel -2


2)



1. Disengage the detent1 (six places), detent2 (eight places), and detent3 (10 places) in this order.
2. While removing the notch part from under the Hinge, remove the Bezel.


# LCD

1)




Peel off the Sheet (Hinge).

2)



Remove the LCD.


3)



Disconnect the Harness (LCD).

# Magnet


1)



Peel off the Magnet.


# Hinge (L)

1)




Peel off the Tape (GND).

2)



Remove the two screws and remove the Plate Hinge (GND).

3)




Remove the Hinge (L).




## Hinge (R)

1)




Peel off the Sheet (Hinge).

2)



Remove the two screws and remove the Plate Hinge (GND).


3)



Remove the Hinge (R).

## Tape (LCD)


1)



Peel off the Tape (LCD) (four places).


## Antenna (2G/5GHZ-R)

1)



Release the coaxial cable from between the ribs (three places) and the detent (one place).

2)




Remove the Antenna.

# Camera Sheet

**Camera Model**

1)




Peel off the Camera Sheet.

# Antenna Sheet (WAN)

**No-WAN Model**

1)




Peel off the Antenna Sheet (WAN) (two places).

# WWAN Antenna (AUX)

**WAN Model**

1)


Coaxial Cable Coming from  
WWAN Antenna (AUX)



Release the coaxial cable from the detent (one place).

2)

WWAN Antenna (AUX)




Remove the WWAN Antenna.

# WWAN Antenna (Main)


**WAN Model**

1)

**Camera Model****No-Camera Model**

Release the coaxial cable from between the ribs (three places).

2)




Remove the WWAN Antenna.

# Protection Sheet (NC / FPC)


**No-Camera Model**

1)



Peel off the Protection Sheet (NC).

2)




Peel off the Protection Sheet (FPC).



## Camera Module -1


Camera Model

1)




Peel off the adhesive tape part (two places).

2)




Remove the Camera Harness.

3)



Release the convex part from the detent A and the shaded area from the detent B, and remove the Camera Holder.

4)




Remove the Camera Module.

## Camera Module -2


**Camera Model**

5)



Disconnect the FPC.


6)



Remove the Ground (Camera).


## Antenna (2G/5GHZ-L)

1)



Release the coaxial cable from between the ribs (two places).


2)



Remove the Antenna.


## Sheet (Logo), Tape (LCD Bezel)

1)



Peel off the Sheet (Logo) (two places).

2)



Peel off the Tape (LCD Bezel).

# Update History

[ADD]---Addition [DEL]---Deletion [CHG]---Change [COR]---Correction [MA]---Model Addition

Date		Contents	Version No.
-	-	-	-