

Chapter 1. Disassembly & Assembly Guide


1-3. Disassembly & Assembly

- Palmrest Block -

P-1 Palmrest Block Disassembly


Cushion (Palm-R), Sheet (Speaker)

1)



Peel off the Cushion (Palm-R).

2)




Peel off the Sheet (Speaker) (two places).

Cushion


ODD (Super Multi) Model

1)



Peel off the Cushion (Center).


2)



Peel off the Cushion (three places).


FPC-130

1)




Raise the lock lever to release the lock and disconnect the Membrane coming from the Keyboard.

2)



Peel off the Tape (Common).

3)




Raise the lock lever to release the lock and disconnect the FPC.

RW Module -1


Felica Model

1)




Disconnect the FFC.

2)




Remove the screw.

3)



While removing the convex part from under the A part, remove the RW Module.

4)




Release the FFC from under the detent (two places), and remove the two screws.

RW Module -2


Felica Model

5)




Remove the RW Module.

6)



Peel off the Ferrite Sheet (Felica).


7)



Disconnect the FFC.


FMC-3

1)



Raise the lock lever (two places) to release the lock, and disconnect the FMC (two places).


2)



Remove the FMC-3 while releasing the convex part from the detent A, and shaded area from the detent B by sliding the FMC-3.


SWX-284 Board

1)



Remove the two screws and disengage the detent (two places).


2)



While releasing the SWX Board from under the detent (two places), remove the SWX Board.

Parts of the SWX-284 Board


1) **FP Model**



Peel off the IFX Board.


* Adhesive tape is attached on the back side.

2) **FP Model**



Turn over the SWX Board, disconnect the FPC, and remove the IFX Board.


3)



Peel off the Sheet (Button TP).

Sheet (Palm)


1)



Peel off the Sheet (Palm) (three places).

Touch Pad


1)



Remove the two screws.

2)


Felica Model



Disengage the detent A (two places) while releasing the rib from the hole, and remove the Button (TP) while taking it out from under the detent B (two places).


3)

No-Felica Model



Disengage the detent A (two places) and the detent B (two places) in this order while releasing the rib from the hole and remove the Button (TP).


4)



Peel off the Touch Pad.


Sheet

1)




Peel off the Sheet (two places).

2)




Peel off the Sheet (Palm-F).

3)

Felica Model

Peel off the Sheet (Palm-R).


4)

No-Felica Model

Peel off the Sheet (Palm-F).


Button (S1S2 / Eject)

1)



Peel off the Button (S1S2) from adhesive tape (three places).

2)




Peel off the Button (Eject) from adhesive tape (two places).

Cover (Felica)


Felica Model

1)



Slide the Cover (Felica) in the direction of the arrow to disengage the detent (three places).

2)



While raising the front side of the Cover (Felica) a bit, remove the Cover by sliding it.

Update History

[ADD]---Addition [DEL]---Deletion [CHG]---Change [COR]---Correction [MA]---Model Addition

Date		Contents	Version No.
-	-	-	-