

Chapter 1. Disassembly & Assembly Guide


1-3. Disassembly & Assembly

- Drive Block -

D-1 Drive Block Disassembly

ODD (Blu-ray) Model


Bezel (ODD), FPC




While disengaging the detent (three places) in order, remove the Bezel (ODD).

*About the detent of 1: While raising the A part a bit, pull out the Bezel in the direction of the arrow to disengage the detent.

Remark



Direction of Detent




Disconnect the FPC.

Bracket (ODD L-U)

U-CTO or L-CTO Model



1)




Remove the screw and remove the Bracket (ODD L-U).

Bracket (ODD FR-J / ODD FL-J)

Except U-CTO or L-CTO Model




1)



Remove the screw (one place each) and remove the Bracket (two places).

Update History

[ADD]---Addition [DEL]---Deletion [CHG]---Change [COR]---Correction [MA]---Model Addition

| Date | | Contents | Version No. |
|------------|---|------------------|-------------|
| 2008.08.25 |  | [MA] (Page 3, 4) | 1.10 |