


Chapter 1. Disassembly & Assembly Guide

1-1. Work Flow

→ ... Removal

Main Section



Battery Pack/
Cap (Power / DC)/
Memory



Palmrest



Support Cushion/
HDD/SSD/
Optical Disc Drive/
Frame (Palmrest)



Reserve Battery/
Sheet (BTM / Dock)/
Optical Disc Drive/
Insulating Tape/
Harness (Power)/
Antenna (2.4GHz)/
Card (EVDO/HSDPA)/
IFX-498 Board/
Ferrite Sheet (CPU)/
Sheet (SIM)/
Bracket (ODD F-U)/
Switch (WLAN)/
Bluetooth Module/LCD



ANL-90 Board/
IFX-496 Board/
Button (Power)/
CNX-404 Board/
FPC-122/
IFX-502 Board/
IFX-497 Board/
Mother Board




Express Card Connector
(Frame)/
Harness (RJ45)/
CNX-405 Board/
Other

Palmrest Block



Cushion (Palm -R)/
Sheet (Speaker)/
Cushion/FPC-130/
RW Module/FMC-3/
SWX-284 Board/
Sheet (Palm)/
Touch Pad/Sheet/
Button (S1S2)/
Button (Eject)/
Cover (Felica)

Drive Block



Bezel (ODD)/FPC/
Bracket (ODD L-U)/
Bracket (ODD-Wing)/
Bracket (ODD FR-J)/
Bracket (ODD FL-J)

LCD Section



Cap (Hinge)/
Cover (Hinge)/
Housing (Bezel)/LCD/
Magnet/Hinge (L)/
Hinge (R)/Tape (LCD)/
Antenna (2G/5GHZ -R)/
Camera Sheet/
Antenna Sheet (WAN)/
WWAN Antenna/
Protection Sheet (NC)/
Protection Sheet (FPC)/
Camera Module/
Antenna (2G/5GHZ -L)/
Sheet (Logo)/
Tape (LCD Bezel)

Mother Board Block



Attachment/Heatsink/
DC Fan/CPU/
Harness (DC Jack)/
Other