

# Chapter 1. Disassembly & Assembly Guide

## 1-3. Disassembly & Assembly

### - Drive Block -

#### D-1 Drive Block Assembly

***ODD (Super Multi) Model***


Note: For the attached articles, check the position attached to the parts before replacing, and attach them to the same position.

## Bracket (ODD FL-J / ODD FR-J)

Except U-CTO or L-CTO Model




1)



Install the Bracket (two places), and tighten the screw (one place each).


## Bracket (ODD-Wing)

1)



Attach the Cushion (OP).

2)




Attach the Sheet (ODD) while applying it to the wall (two places).

3)

Screw: Except U-CTO or L-CTO --- B6  
U-CTO or L-CTO --- B9



Back Side




Install the Bracket (ODD-Wing), and tighten the two screws.

## Bracket (ODD L-U)

U-CTO or L-CTO Model




1)



Install the Bracket (ODD L-U), and tighten the screw.


## FPC, Bezel (ODD)

1)



Connect the FPC.


2)



Engage the detent (three places) in order and install the Bezel (ODD).

# Update History

[ADD]---Addition [DEL]---Deletion [CHG]---Change [COR]---Correction [MA]---Model Addition

Date		Contents	Version No.
2008.08.25		[MA] (Page 2, 3, 4)	1.10