

Chapter 1. Disassembly & Assembly Guide


1-3. Disassembly & Assembly

- Mother Board Block -

M-1 Mother Board Block Disassembly

Attachment -1


1)



Peel off the Cushion (Lower) and Sheet (NC).


2)

CPU (Core 2 Duo/T9600/2.8GHz) Model




Peel off the Sheet (Air Duct).

3)



Peel off the Ferrite Sheet (MBX).


4)



Peel off the Thermal Sheet (GPU-KBD).


Attachment -2

5)




Peel off the Cushion (Up).

6)



Peel off the Thermal Sheet (Power).


7)



Peel off the Thermal Sheet (VRAM).


Heatsink

1)




Disconnect the Harness coming from the DC Fan.

2)




Remove the three screws.

3)



Remove the Heatsink.


4)



Peel off the Thermal Sheet (GMCH).


CPU

1)



Peel off the Thermal Sheet (CPU).


2)



Rotate the lock screw in the direction of the arrow to release the lock.

* Use a 4 mm flat-head (-) screwdriver.

3)




Remove the CPU vertically.

* Be careful not to bend the pins.

Harness (DC Jack)


1)



Disconnect the Harness (DC Jack).

Service A-ban

1)



Update History

[ADD]---Addition [DEL]---Deletion [CHG]---Change [COR]---Correction [MA]---Model Addition

Date		Contents	Version No.
-	-	-	-