

Note for Z Series -1

Precautions for Handling the Drive


In performing a repair, observe the following precautions.



1. Do not turn the power switch on until the Palmrest and the keyboard are installed completely.



2. If the power switch is to be turned on with the set in disassembled state, be sure to load a dummy disc in the drive.




3. If the power switch is to be turned on with the set in disassembled state for checking the drive condition, be sure to turn the power switch on with the tray drawn out.

Note for Z Series -2

Note for WAN Board Replacement

When replacing the WAN Board, change the barcode label on the bottom.



1. Peel of the barcode label which is attached to the bottom. (Refer to the figure above.)
2. Attach the barcode label which is included with the WAN Board to the position where you peeled off the label in the step 1.